



**Part Number:** CAI-PT001B, CAI-PT001R



Part List:

Cold air intake pipe	2 Pieces
Coupler	2 Pieces
Elbow coupler	1 Piece
Clamp	7 Pieces
Air filter	1 Piece
Universal bracket	1 Set

**Note:** Remove the negative battery terminal before starting this installation. The installation of this cold air intake does require mechanical skills.

- 1- Unplug MAF harness from the MAF sensor.
- 2- Remove the air filter box and air intake duct leading to the throttle body.
- 3- Connect a reducer coupler onto the throttle body with 2 clamps. Tighten the clamp on the throttle body at this point.
- 4- Insert the straight intake pipe into the reducer coupler on the throttle body.
- 5- Connect the elbow coupler to the end of the straight intake pipe with 2 clamps.
- 6- Slip the stock MAF sensor into the elbow coupler. Semi-tighten the clamp.
- 7- Install the last piece of reducer coupler to the other end of the MAF sensor with 2 clamps. Tighten the clamp on the MAF sensor.
- 8- Insert the air filter to the L-shape pipe (the bend side) and tighten the clamp on the filter neck.
- 9- Install the intake assembly to the reducer coupler on the MAF sensor.
- 10- Ensure that the air filter is not touching any part of the vehicle. Position the inlet pipe for best fitment. Be sure that the pipe or any other component is not in contact with any part of the vehicle. Tighten the clamps at the throttle body and reducer coupling. Tighten the bolt on the intake resonator mounting bracket. Check for proper hood clearance. Re-adjust pipes if necessary.
- 11- Installation completed.

For the idea of the Universal Bracket Installation (Not for all intakes), please visit <http://www.youtube.com/watch?v=IMIXVYGW2Zk>.

If you have any questions about the product, please contact us thru Ebay Message.