

RTUNES RACING



Part Number: SI-CH013B, SI-CH013R



Part List:

Air intake pipe	1 Piece
Coupler	1 Piece
Clamp	3 Piece
Air filter	1 Piece
Universal bracket	1 Set

Note: Disconnecting the negative battery terminal before starting this installation. The installation of this air intake does require mechanical skills.

- 1- Remove bolts securing OEM air filter box, loosen clamps on stock rubber intake tube.

- 2- Remove the stock rubber intake tube, and the stock air filter box by pulling upward.
- 3- Insert the reducer coupler onto the throttle body with 2 clamps. Tighten the clamp on the throttle body.
- 4- Insert the intake pipe into the reducer coupler, semi-tighten the clamp.
- 5- Install the air filter to the open end of the intake pipe. Semi-tighten the clamp on the filter neck.
- 6- Here is the idea of how to install the universal bracket.



- 7- Ensure that the air filter is not touching any part of the vehicle. Position the inlet pipe for best fitment. Be sure that the pipe or any other component is not in contact with any part of the vehicle. Tighten the clamps at the throttle body and reducer coupling. Tighten the bolt on the intake resonator mounting bracket. Check for proper hood clearance. Re-adjust pipes if necessary.
- 8- Installation completed.

For the idea of the Universal Bracket Installation (Not for all intakes), please visit <http://www.youtube.com/watch?v=IMIXVYGW2Zk>.

If you have any questions about the product, please contact us thru Ebay Message.